

LENS CLEANING KIT INSTRUCTIONS

PLEASE READ THOROUGHLY BEFORE PROCEEDING. YOU ARE LIABLE FOR ANY DAMAGE CAUSED TO THE EQUIPMENT.



STEP 3: Carbon Sponge



If you notice stubborn grime or dust, we are going to use the carbon brush/sponge to gently pass all around the surface of the lens glass - **otherwise skip to step 5**. We only want to use this pen to clean the lens glass and nothing more.

STEP 1: Blow Particles Off



The first thing we want to do is using the blower in your kit, blow the most particles off the lens or camera. The key is to tilt your lens or camera facing down meanwhile doing this, so the particles can fall downward and not inward.



STEP 4: Cleaning Tissue



To use the cleaning tissue, start in the center of the lens glass and make circular movements slowly expanding outwards. Do not apply too much pressure. This will bring any lingering dust to the edges where they can be pulled off with the tissue. Use more than one if necessary.

STEP 2: Brush the Dust and Grime



Now that we have blown off the most particles off the camera or lens, we want to try to remove any stuck on dust or grime with the stand alone brush. Remember to do this **gently**. We want to make sure we get every surface of the lens and camera, if you using a zoom lens place your lens in manual mode and zoom in and out to get every part.



STEP 5: Cleaning LCD Screen and View Finder



To clean the viewfinder, use the non-alcoholic solution provided to spray a corner of the micro fibre cloth. **DO NOT** spray directly onto the camera or lens. Using the wet side, clean the relevant surface and then go over it with a dry part of the cloth.

